



# FURNITURE POLISH

- SILICONE BASED SPRAY POLISH
- QUICK DEEP SHINE
- EASY TO USE

ORDER CODE

**014.002**

**H04**

## DESCRIPTION

**MERLIN H04 FURNITURE POLISH** is a superior aerosol spray polish for furniture, tiles, marble, stainless steel and most plastic and vinyl coated surfaces. **MERLIN H04 FURNITURE POLISH** removes finger marks, surface dirt, smudges, etc. **MERLIN H04 FURNITURE POLISH** produces a glowing finish to be proud of and eliminates the need for vigorous polishing and brings up a brilliant, protective, long lasting shine.

## USES

**MERLIN H04 FURNITURE POLISH** is suitable for furniture, tiles, marble, stainless steel and most plastic and vinyl coated surfaces.



## DILUTIONS AND DIRECTIONS

Shake well before use. Holding the container as near upright as possible, give **MERLIN H04 FURNITURE POLISH** a light spray. Wipe gently with a soft duster and leave to dry. For small areas, spray a small amount of **MERLIN H04 FURNITURE POLISH** directly onto your duster and polish as usual.

**N.B. Not suitable for floors.**



## SAFETY INFORMATION

**Keep out of reach of children.** May produce an allergic reaction. Extremely flammable aerosol. Pressurised container: May burst if heated. Keep away from heat, sparks, flames, hot surfaces. No smoking. Do not spray on an open flame or other ignition source. Do not pierce or burn, even after use. Protect from sunlight. Do not expose to temperatures exceeding 50°C/122°F.

Contains Methylchloroisothiazolinone.



**400ml**



0345 565 0939 | [SALES@SELDRAM.CO.UK](mailto:SALES@SELDRAM.CO.UK) | [WWW.SELDRAM.CO.UK](http://WWW.SELDRAM.CO.UK)