

GLASS RENOVATOR

021.007

ORDER CODE

- REMOVES STAINS & BUILD-UP OF MINERAL DEPOSITS
- RESTORES A SPARKLING FINISH TO GLASSES
- RENOVATES & REODORISES GLASSWASHING MACHINES

C16

DESCRIPTION

MERLIN C16 GLASS RENOVATOR is a specialist detergent for use in automatic glasswashing machines to renovate and restore the appearance of drinking glasses. MERLIN C16 GLASS RENOVATOR can also be used to deodorise the machine itself.

USES

MERLIN C16 GLASS RENOVATOR is recommended for use in pubs, restaurants and hotels to keep glassware in great condition.



DILUTIONS AND DIRECTIONS

RENOVATING DRINKING GLASSES:

Use MERLIN C16 GLASS RENOVATOR at a 1% dilution through the glass washing machine at approximately 60°c. Pour 100ml of MERLIN C16 GLASS RENOVATOR into a plastic measuring jug & pour into the machine before the wash cycle. Alternatively, feed through the glass wash dispenser for a day to renovate the appearance of the glasses.



DEODORISING AND CLEANING ENCLOSED GLASSWASHING MACHINES:

Pour 200ml to 1 litre of **MERLIN C16 GLASS RENOVATOR** from a plastic measuring jug into the enclosed glass washing machine & run at approximately 60°c through a wash cycle.

SAFETY INFORMATION

Causes severe skin burns and eye damage. Very toxic to aquatic life. **Keep out of reach of children**. Wear eye protection. Wear protective gloves. Wash hands thoroughly after handling. Avoid release to the environment. **IF IN EYES**: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **If eye** irritation persists: Get medical attention. **IF ON SKIN (or hair)**: Remove immediately all

13.5

contaminated clothing. Rinse skin with water. If skin irritation occurs: Get medical attention. Take off contaminated clothing and wash before reuse. Collect spillage. For professional use only.



